

Operating instructions Workabout Pro3

HHT Scanners WorkAbout Pro3

- Scanner Pro3 is with blank edge around screen and named **workabout Pro³**

Power On/Off:

- Use button **Power On/Off**

Restart:

- Press and hold **FN-F4–Power On/Off** for about 5 sec.

Scanner power up/down:

- Power down: Press F1 - Power up: Press F4

Check battery power:

- Press **FN** and 1

Normal Use:

- Start "Pack and Sea" program
- Login with your username and password
Scanner must be online
- Scan boxes, scan to other customers
The HHT scanner is able to work offline, Data will be delivered automatically when online

Auction scanning:

- *The HHT scanner must be online*

Always leave the terminal logged out

- Program-updates are automatically installed when logging in to the Pack and Sea system.

The "Dot" in the login window indicates:

- **GREEN:** When all data has been send to the server
- **YELLOW:** When data traffic is ongoing
- **RED:** When data can't be delivered to the server

Network management:

Scanner Pro3 uses SCU for network management:

- Create profile
- Change profile

SCU must be used when the scanner indicates "No connection to the server"

In case of network problems – see the guide "*Guide PRO2 and PRO3 - Wireless Network Setup WAP2 G2 and G3*"

In case of problems contact:

Bent +4540586083 or Susan +4530115298. Pack and Sea contacts Lyngsoe Systems.